## NELSON<sup>™</sup> HEAT TRACING SYSTEMS SPECIFICATION / APPLICATION **TE760-SV THERMOSTAT** INSTALLATION

## DESCRIPTION



These thermostats are used for high temperature piping on freeze protection and process maintenance applications in hazardous locations. For MI cable applications that require design voltages less than 120VAC, adjustable between 30 to 100VAC.

#### **ENCLOSURE** Cast Aluminum

**CLASSIFICATIONS** NEMA Type 4, 7, 9 IP66

#### **TEMPERATURE RANGE**

0 to 538°C (32 to 1000°F)

#### CAPILLARY Ler

Length	Material
3m (10ft.)	Incoloy 825

Max. Bulb Temperature 593°C (1100°F)


**ELECTRICAL DATA** Load: 5 amp resistive @ 30 to 100VAC Control Voltage: 120VAC

**CALIBRATION ACCURACY** ±1% of span

#### SWITCH TYPE

Single Pole Double Throw

# OUTLINE




#### Approvals:

- FM Class I; Div. 1; Groups B, C, D Class II; Div. 1; Groups E, F, G Class I; Zone 1; AEx d IIB+H<sub>2</sub>
- CSA Class I; Div. 1; Groups B, C, D Class II; Div. 1; Groups E, F, G
  - Class I; Zone 1; Ex d IIB+H<sub>2</sub>

# NELSON™ HEAT TRACING SYSTEMS<br/>SPECIFICATION / APPLICATIONTE760-SV THERMOSTATINSTALLATION

# INSTALLATION




#### **INSTALLATION NOTES:**

- Securely mount thermostat enclosure and connect to power wiring.
- Verify thermostat set point is at the desired maintenance temperature.
- Close enclosure cover to prevent damage from inclement weather.
- Insure all fittings associated with the power wiring are installed per applicable codes.
- When conduit type systems are used, low point drains / conduit drains are highly recommended.

### ANNUAL MAINTENANCE:

Spray a coat of lubricant and rust preventative such as CRC Stor & Lube on the electrical wire connections.

## WIRING DIAGRAM



Nelson Heat Tracing Systems products are supplied with a limited warranty. Complete Terms and Conditions may be found on Nelson's website at www.nelsonheaters.com.